



View Reports

Follow these quick steps to view your reports in DataEngine Live.

Written By: Support



The screenshot displays the Farmobile DataEngine Live interface. On the left is a navigation menu with options: Machines, Fields, Notes, File Transfer, Data Import, Reports (highlighted), Downloads, Inputs, Account, Farmobile Shop, and How-To Guides. The main content area shows a report for 'Field A' under 'Grower A'. The report includes a satellite map of the field with a green overlay indicating planting activity. Below the map is a legend for 'Average Population - kseeds/ac' with a scale from 0.1 to 40. The report details are as follows:

Plant		
Corn CROP	DKC52-61RIB , P0688AM SEED VARIETY	32.33 kseeds/ac AVG POPULATION
82.92 ac BOUNDARY	82.42 ac WORKED	99.39 % FIELD % COMPLETE

INTRODUCTION



- Machine Reports are automatically generated based on machine activity.
 - All users receive Daily, Weekly, and Monthly machine utilization reports.
- Field Activity Reports are automatically generated based on agronomic activity within a field boundary.

Step 1 — Select Reports from the Farmobile DataEngineSM Menu





- Selecting Reports from the Farmobile DataEngine menu will open the Reports page with all of your reports listed to review.

Step 2 — Select the Report Name to View the Report



- The name of each report is a hyperlink to view your report details.

Step 3 — Review Report Details



- Once your report is open, you can review all the details to assist in managing your operation.
- You also have the ability to 'Download' a report from this page as well to share with an advisor. For assistance on how to download a report, please refer to the Download Report guide.