





# Moving the Transition Tower

When adding color to a model in CANVAS, the transition tower can sometimes be positioned off the print bed.

Written By: Mosaic Support



## Step 1 — Move Tower



- Open your project.
- Select **Transition Tower** in the *Object Browser*, or click on the Transition Tower directly. **Transition Tower** will then be highlighted.
- On the left side of the screen, select *Move*. Using the controls, manually move the transition tower back onto the print bed.
- If the transition tower does not fit even when on the bed, use the *Scale* option to adjust the shape of the transition tower. You can adjust the width and length of the tower by manually inputting values into the respective fields, or incrementally increasing or decreasing a dimension.
- To move your entire model, follow the same steps above but select **Group** in the Object Browser instead.

If you have any additional questions, please send us a message at [support@mosaicmfg.com](mailto:support@mosaicmfg.com)