




HOW TO CHANGE CAMERA RESOLUTION SETTINGS

Written By: Q-See EP




Step 1 — HOW TO CHANGE CAMERA RESOLUTION SETTINGS




- Click **Start** in the Menu Bar

Step 2




- Click **Settings**

Step 3




- Click **Encode Parameters** in the Record tile.

Step 4




- ☑ Select the recording method to adjust:
 - **Event Recording Streams:** *Motion and Alarm Recording*
 - **Timing Record Stream:** *Schedule and Manual Recording*

Step 5




 **To modify the Resolution for multiple cameras at once:**

- Click **Resolution**

 Cameras supporting the same resolutions will be grouped.

Step 6



- Click the **Resolution** dropdown.
- Select the desired **Resolution**.


Step 7



✦ To make changes to a different group of cameras:


- Click the **Down Caret**

Step 8



- Once completed, Click **OK**


Step 9



To make changes to a specific camera:


- Click the **Resolution** dropdown for the specified camera and make a selection.

Step 10



- Once completed, click **Apply**


Step 11




 To make changes to the Sub Stream (Mobile Viewing Settings):

- Click **Stream Settings**

Step 12



 Changes to the Sub Stream can be made using the same process mentioned in previous steps.

- Once completed, click **Apply**