


Al Recording Setup


Written By: Q-See



INTRODUCTION

Al Recording is only supported by the QCN8093B with the latest Firmware. The only NVR's supporting Al are the QC888, QCK81, and QC826 with the latest firmware.

Step 1 — Al Recording Setup




- Right-click anywhere on your screen.
- Click Main Menu


Step 2



Select Event under "Setting"



- Select IVA
- Select the **Channel** you wish to setup.
- Click Add



- Select the **Type** of rule you wish to create.
- **Tripwire**: Cross a line to trigger recording.
- intrusion: Define an area that if entered, will trigger recording.




Click Draw



- Ensure that **Al Recognition** is checked.
- Select **Person** and/or **Vehicle** to include them as recognizable objects.



- Left-click once to start the line.
 Left-click a second time to mark the end.
- **Right-click** once to finalize the line.



- Select the **Direction** you want to track movement.
- Click Save



Click Trigger



- Click **Set** to configure the trigger schedule.
- Click OK



- Repeat Steps 3 9 to create more rules.
- Click Apply
- Click Camera





- Click Rec Schedule
- Select the **Channel** to configure.
- Click the Gear icon for one of the days of the week.



- Define the **Period** you want scheduled.
- Copy the schedule as needed.
- Check IVA for the desired period.
- Click Save

Step 14





Click Apply then OK

 Λ

Detected objects will appear in the live feed with blinking boxes.